

Stick-A-Switch™ (Model SS13A) Installation and operating instructions

The SS13A works with the RR500 (part of the RC500) and the TM751 (part of the RC6500). It lets you turn on and off three individually coded X10 Modules and brighter and dim lights connected to Lamp Modules and Wall Switch Modules. In the default site (after first fitting the battery) the SS13A is set to Housecode A. The top three ON/OFF rocker keys control modules set to Unit Codes 1, 2, 3. The bottom rocker key brightens and dims lights connected to Lamp and Wall Switch Modules.

1. Plug in an X10 Transceiver (RR500 or TM751, sold separately).

2. To turn on or off X10 Modules set to Unit Codes 1, 2, or 3 on Housecode A: press the left or right side of the first, second or third rocker key. To brighten or dim Lamp Modules or Wall Switch Modules, press the number button first, then press and hold the left or right side of the bottom rocker key. Attach the SS13A to a wall using double sided tape or Velcro™. If you want to control Modules 1, 2 and 3 on Housecode A, that's it. You don't need to read any further.

To change the Housecode


- Press and hold the first (top) ON rocker key. The red LED flickers. 3 seconds later, the LED blinks the current setting: 1 blink for Housecode A, 2 blinks for B, ..., 16 blinks for P.
- Release the first (top) ON rocker key.
- Press and release the first (top) ON rocker key the appropriate number of times for the Housecode you want to set. Once for A, twice for B, etc. The LED blinks for each press. **IMPORTANT:** Hold the button on your last press. 3 seconds later, the red LED blinks back the new setting, e.g. 3 blinks for Housecode C. If you do not follow this programming sequence, the LED will stay on for 1 second and your existing setting will not be changed.

To change the Unit Code for the first (top) rocker key (the second and third rockers are always one # higher than the first, i.e. if you set the first rocker key to 6, the second rocker key controls 7, and the third control 8, etc.

- Press and hold the top OFF rocker key. The red LED flickers. 3 seconds later, the LED blinks the current setting: 1 blink for Unit Code 1, 2 blinks for 2, 16 blinks for 16.
- Release the top OFF rocker key.
- Press and release the top OFF rocker key the appropriate number of times for the Unit Code you want. **IMPORTANT:** Hold the key on your last press. 3 seconds later the new code blinks back. If you do not follow this programming sequence, the LED will stay on for 1 second and your existing setting will not be changed.

To change battery: open battery holder and fit a CR2032 Lithium 3V battery. Observe polarity.

F.C.C. CAUTION - THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION. NOTE: NO CHANGES OR MODIFICATIONS MAY BE MADE TO THE UNIT. ANY CHANGES MADE TO THE UNIT WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.



Press left side to turn on, right side to turn off modules set to Unit Codes 1, 2, and 3 on Housecode A (the default setting). Then press and hold left side to brighten or right side to dim.

Replace battery with CR2032, 3V lithium type.

X10 (USA) INC. LIMITED 1-YEAR WARRANTY

X10 (USA) Inc. warrants X10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X10 (USA) Inc. agrees to repair or replace, at its sole discretion, a defective X10 product if returned to X10 (USA) Inc. within the warranty period and with proof of purchase.

If service is required under this warranty:

1. Return the defective unit postage prepaid to X10 (USA) Inc. (see address on back)
 2. Enclose a check for \$4.00 to cover postage and handling.
 3. Enclose a dated proof of purchase.
 4. X10 is not responsible for shipping damage.
 5. Units to be returned should be packed carefully.
- For additional warranty information, contact X10 (USA) Inc.

Your Name
Address
Date Purchased 19..... Store where purchased

SS13A-299

FROM

X10.com, Inc.

3824 North 5th St., Suite C, North Las Vegas, NV 89030

First Name	Last Name	
<input type="text"/>	<input type="text"/>	
Street Address - No P.O. Box numbers (for U.P.S.)		
<input type="text"/>		
City	State	Zip
<input type="text"/>	<input type="text"/>	<input type="text"/>

CONTENTS - MERCHANDISE

RETURN POSTAGE GUARANTEED

POSTMASTER: THIS PARCEL MAY BE OPENED FOR POSTAL INSPECTION

X10.com, Inc.
3824 North 5th St., Suite C,
North Las Vegas, NV 89030

Mini Timer MTS22/MT10A

A Controller, Timer and Alarm Clock all in one! Programs up to 4 modules to go on and off at specific times, twice a day. Controls 8 modules instantly. Dims lights too.

Maxi Controller SC503

Lets you control up to 16 X10 Modules at the touch of a button from anywhere in the house. Dims lights too!

Mini Controller MC460

Lets you control up to 8 X10 Modules at the touch of a button from anywhere in the house. Dims lights too!

2-Way Home Control Interface CM11A

Set up from an IBM compatible PC to control up to 256 X10 Modules. ActiveHome software & cable included.

Thermostat Set-Back TH2807

Automatically sets-back your central heating/air conditioning. Mounts on the wall under your existing thermostat and plugs into an Appliance Module.

Telephone Responder TR16A

Lets you control up to 10 lights and appliances from any outside touch-tone phone.

Wireless Remote Control System RC5000

Lets you control 16 X10 modules from inside or outside your home. Can also dim and brighten Lamp Modules and Wall Switch Modules. Works with the HR12A PalmPad Remote and X10RF Wall Switches (RW684, RW694, RW724, SS13A, SS15A).

Lamp Module LM465

Can be Dimmed and Brightened from any X10 Controller. Responds to "All lights on". Rated for 300 W. Incandescent only. *2-Way version LM14A*

Appliance Module - AM486/AM466

Two pin polarized (AM486) or 3 pin grounded (AM466) for controlling an air conditioner, TV, stereo, etc. anywhere in the home. Rated 15A for heaters, coffee pots, etc., 1/3 H.P. for motors; 400W for TVs, 500W for lamps. *2-Way versions available AM14A (2 pin), AM15A (3 pin).*

Wall Switch Module WS467

For controlling important indoor and outdoor security lights. Replaces your existing wall switch and installs like a regular dimmer. Dimmed/brightened from any X10 Controller. Rated 500W incandescent only.

3-Way Wall Switch Module WS4777

For controlling a light which is controlled by two switches. Same features as WS467.

Split Receptacle Module SR227

Replaces existing wall outlet. The top outlet functions like an Appliance Module, the bottom one is a regular outlet. Rated 15A. Controls ANYTHING which normally plugs into a regular AC outlet.

Universal Module UM506

Isolated contact relay and beeper. Can be set for momentary or continuous operation. Not compatible with DS7000 and DC8700 security systems.